


# Maytag LSE7806ACQ 11 - TOP & LID (LSE7806ACQ/ADQ)



Maytag [Residential Maytag LSE7806ACQ Stacked Washer and Dryer Parts](#) Parts Diagram 11 - TOP & LID (LSE7806ACQ/ADQ)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">22001585</a>			Harness, Wire
"	22001427		Not Available	WIRE HARNESS (UPR) NA
2	<a href="#">22001939</a>			Harness, Lid Switch
3	<a href="#">22001194</a>			Clip, Spring
4	<a href="#">22001001</a>			Screw
5	<a href="#">208823</a>			Pc Switch, Lid
6	22001581	<a href="#">12001514</a>		Switch-Lid
"	<a href="#">22001555</a>			Fuse
7	22002652		Not Available	LID, WITH LEGEND (BSQ)
8	<a href="#">214354</a>			Screw, Top Cover To Cabnt.
9	<a href="#">22002646</a>			Cover, Top
10	<a href="#">212716</a>			Bumper, Lid
11	22002596	<a href="#">22001008</a>		Cup, Bleach
12	215374		Not Available	GASKET FOR BLEACH CUP
13	<a href="#">22001189</a>			Rod, Restraint
14	<a href="#">22001208</a>			Rod, Counter Balance

15	<a href="#">Y216184</a>	Spring, Counter Balance
16	<a href="#">22001193</a>	Bearing, Counter Balance
17	<a href="#">207166</a>	Switch, Check
18	<a href="#">22001283</a>	Trigger
19	<a href="#">22001183</a>	Screw
20	<a href="#">22001285</a>	Holder, Switch
21	<a href="#">22001286</a>	Switch, Arm
22	<a href="#">22001287</a>	Spring, Switch
23	<a href="#">22001250</a>	Glide, Switch Arm

