


# Maytag MDG13CSAKL 03 - FRONT



Maytag [Residential Maytag MDG13CSAKL Dryer Parts](#) Parts Diagram 03 - FRONT  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	NLA		Not Available	COVER, TOP (ALM)---NA
002	NLA		Not Available	PLATE, COVER
003	NLA		Not Available	CABINET (UPR-ALM)
004	306530		Not Available	BASE ASSEMBLY (LOWER)
005	910768	<a href="#">M0280301</a>		Tie Electr
006	911050	<a href="#">4312464</a>		Screw
"	NLA		Not Available	SPACER ASSEMBLY (ALM)
"	Y310632	<a href="#">1163839</a>		Screw
007	NLA		Not Available	CABINET (LWR-ALM)
008	Y302699	<a href="#">22003428</a>		Leg, Adjustable
009	<a href="#">210684</a>			Foot, Adjustable Leg
010	<a href="#">210385</a>			Lock Nut For Adjustable Leg
011	314663	<a href="#">214354</a>		Screw, Top Cover To Cabnt.
012	33001486	<a href="#">98008544</a>		Screw
"	NLA		Not Available	PANEL, FRONT (ALM)---NA
013	211168	<a href="#">W10139210</a>		Screw, 8-18 X 5/16

014	33001203	Not Available	PANEL, CLEAR INNER (W/SEAL)
015	<a href="#">314974</a>		Handle, Door
016	NLA	Not Available	PANEL, OUTER (ALM)
017	33001711	<a href="#">33002936</a>	Medallion-
018	<a href="#">Y313559</a>		Screw
019	<a href="#">213007</a>		Xfor Cabinet See Cabinet, Back
020	<a href="#">22001496</a>		Front Panel Fastener And Screw
021	310933	<a href="#">33002194</a>	Nut, Speed

