


Maytag MDG270SAWW 03 - CONTROL PANEL & TOP



Maytag Residential Maytag MDG270SAWW Dryer Parts Parts Diagram 03 - CONTROL PANEL & TOP
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	37001233			Shield, Backguard
2	37001212			Facia
3	21001965			Frame, Control Panel, Support
4	21001523			Endcap
5	501086	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
6	31001567			Knob/Skirt, Timer
7	56486		Not Available	BRACE, TOP
8	37001031	3370225		Screw
9	37001240			Timer - Dryer
10	21002070			Knob, Selector
11	503688			Screw, 10B-16 X .34 I
12	37001165			Switch, Temp - 4 Position
13	21001517			Shield, Control
14	21001519			Endcap
15	31260			Screw, No.8 X 3/8 Ind H
16	500121	510189		Pad Felt

