


Maytag MDG5960BWW 01 - CABINET-FRONT



Maytag Residential Maytag MDG5960BWW Dryer Parts Parts Diagram 01 - CABINET-FRONT
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	33002627			Cover, Top
"	33001865			Cover, Top
2	33001872	33002891		Pin, Locator
3	22003409	213007		Xfor Cabinet See Cabinet, Back
"	213007			Xfor Cabinet See Cabinet, Back
13	22003639			Cabinet Assembly
"	22003582		Not Available	CABINET, ASSY. (WHT-AS PK)
"	22003367	22004095		Hinge, Plastic
"	22002548	22003639		Cabinet Assembly
"	22001995			Screw Note: Screw, Tumbler Front And Shroud
14	22002049			Clip Note: Clip, Front Panel
15	213280	204439		Screw And Fstner Assembly
16	22001995			Screw Note: Screw, Tumbler Front And Shroud

