


# Maytag MDG7658AWW 01 - CABINET



Maytag Residential Maytag MDG7658AWW Dryer Parts Parts Diagram 01 - CABINET  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">33002627</a>			Cover, Top
2	33001872	<a href="#">33002891</a>		Pin, Locator
3	<a href="#">Y310376</a>			Clip, Door Switch Harness
13	<a href="#">22003639</a>			Cabinet Assembly
"	22003582		Not Available	CABINET, ASSY. (WHT-AS PK)
"	22003367	<a href="#">22004095</a>		Hinge, Plastic
14	<a href="#">22002049</a>			Clip Note: Clip, Front Panel
15	213280	<a href="#">204439</a>		Screw And Fstner Assembly
16	<a href="#">22001995</a>			Screw Note: Screw, Tumbler Front And Shroud
17	<a href="#">Y310376</a>			Clip, Door Switch Harness
18	<a href="#">213007</a>			Xfor Cabinet See Cabinet, Back