


Norge DGN203A 01 - CONTROL PANEL



Norge Residential Norge DGN203A Dryer Parts Parts Diagram 01 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	53-2630		Not Available	PANEL, CONTROL
2	25-7649	910187		Screw
"	25-7702			Speedclip, End Cap To Control Panel
"	35-2488	21001452		Cap- End
"	35-2487	21001451		Cap- End
3	25-7691		Not Available	SCREW, END CAP TO TOP
"	25-7851			Speedclip, End Cap To Top
4	25-7435	33002917		Screw, No.10-16
"	25-7852			Speedclip, Rr Shld To End Cap
5	53-0278		Not Available	TRIM, END CAP (LT)
"	53-0277		Not Available	TRIM, END CAP (RT)
6	25-7760			Screw
7	25-7702			Speedclip, End Cap To Control Panel
8	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping

9	53-1676		Shield, Control
"	31001128	Not Available	SHIELD, CONTROL
"	53-2504	31001193	Pad, Shield
10	35-2688	21001460	Shield, Rear
11	53-1758		Timer
12	25-7435	33002917	Screw, No.10-16
13	53-2637	31001219	Knob Ski
14	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
"	53-0344	Not Available	SWITCH, TEMPERATURE
"	31001129		Switch, Temperature
15	35-4244	21001283	Knob, Selector----Piq
16	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
"	53-1639		Buzzer Assembly
18	31001033	Not Available	MANUAL, USE & CARE
"	31001008		Manual, Use And Care
19	16002081	Not Available	GUIDE, QUICK REF - NORGE

