



**NON – ILLUSTRATED
PARTS**

Includes

Optional Parts

Parts Not Included

Miscellaneous Parts



Whirlpool [Residential Whirlpool WED4700YQ0 Dryer Parts](#) Parts Diagram 04 - OPTIONAL PARTS (NOT INCLUDED)

[Click on the part number to view part](#)

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|-------------------------|-------------------------|--------|----------------------------|
| NI | 279948 | 4392065 | | Kit, Dryer Repair |
| " | 8522199 | | | Accessory Parts |
| " | 3404351 | | | Accessory Parts |
| " | 72017 | | | Paint, Touch-Up |
| " | 350930 | | | Paint, Pressurized Spray B |
| " | 350938 | | | Paint, Pressurized Spray B |
| " | 799344 | | | Paint, Touch-Up) |

