


Whirlpool WFW8300SW03 03 - CONTROL PANEL PARTS

CONTROL PANEL PARTS

For Model: WFW8300SW03
(White/Grey)



4

W10168165

Whirlpool [Residential Whirlpool WFW8300SW03 Washer Parts](#) Parts Diagram 03 - CONTROL PANEL PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10099593			Panel, Control
2	8574963			Knob, Control
3	8571903			User Interface
4	8540558	W10240776		Brace, Top Front
5	8540839			Channel, Water
6	W10160252	W10205839		Control-Elec
7	3390647	488729		Screw
8	W10118622	W10169929		Harness, Wiring
9	8540282	8181661		Screw, Actuator
10	W10015090	489442		Screw 3 2217757 Roller, Front