


# Whirlpool WFW8500SR03 03 - CONTROL PANEL PARTS

## CONTROL PANEL PARTS

For Model: WFW8500SR03  
(White/Metallic)



4

W10205679

Whirlpool [Residential Whirlpool WFW8500SR03 Washer Parts](#) Parts Diagram 03 - CONTROL PANEL PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">W10099592</a>			Panel, Control
2	<a href="#">8574964</a>			Knob, Assembly
3	<a href="#">8574920</a>			User Interface
4	W10161692	<a href="#">W10240776</a>		Brace, Top Front
5	<a href="#">8540839</a>			Channel, Water
6	W10160253	<a href="#">W10205841</a>		Control-Elec
7	3390647	<a href="#">488729</a>		Screw
8	<a href="#">W10184856</a>			Harness, Wiring
9	8540282	<a href="#">8181661</a>		Screw, Actuator
10	W10015090	<a href="#">489442</a>		Screw 3 2217757 Roller, Front