


MISCELLANEOUS PARTS

For Model: WGT3300SQ1
(Designer White)



[Whirlpool Residential Whirlpool WGT3300SQ1 Washer/Dryer Parts](#) Parts Diagram 14 - MISCELLANEOUS PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10118295			Miscellaneous Parts Bag
2	16123			Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
3	356138			Clamp, Hose
5	3357331			Clamp, Drain

