


# Whirlpool WTW5320SQ0 03 - AGITATOR, BASKET AND TUB PARTS

## AGITATOR, BASKET AND TUB PARTS

For Model: WTW5320SQ0  
(White)



8181362

5

Whirlpool [Residential Whirlpool WTW5320SQ0 Washer Parts](#) Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">3949550</a>			Washer
2	<a href="#">358237</a>			Screw And Washer
3	389141	<a href="#">3360824</a>		Auger, Agitator
4	<a href="#">389386</a>			Agitator
5	8528150	<a href="#">W10445870</a>		Ring-Tub
6	<a href="#">3976308</a>			Gasket, Tub Ring
7	3350389	<a href="#">285587</a>		Washer
8	3363662	<a href="#">285748</a>		Cam-Agitator
9	3366877	<a href="#">80040</a>		Dog-Agitator
10	<a href="#">3363661</a>			Bearing, Driven Cam
11	<a href="#">21366</a>			Nut, Spanner
12	8526017	<a href="#">W10389329</a>		Clothes Container, Assembly
13	8519788	<a href="#">387240</a>		Ring, Balance
14	<a href="#">2219077</a>			Clip, Pressure Switch Hose
15	<a href="#">63849</a>			Strain Relief, Power Cord
16	<a href="#">389140</a>			Tub Block, Basket Drive

17	<a href="#">383727</a>	Gasket, Centerpodt	
18	3347780	<a href="#">353244</a>	Hose, Pressure Switch
19	3347674	<a href="#">285727</a>	Agitator
20	63973	<a href="#">3362061</a>	Cap
21	<a href="#">358912</a>	Seal, Agitator Cap	

