Jenn-Air JDE2000WC 02 - CONTROL PANEL



Jenn-Air Residential Jenn-Air JDE2000WC Dryer Parts Parts Diagram 02 - CONTROL PANEL
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	31001199		Not Available	PANEL, CONTROL (WHT)
2	25-7649	910187		Screw
3	25-7702			Speedclip, End Cap To Control Panel
4	21001245			Trim, Endcap
"	21001246		Not Available	TRIM, ENDCAP (LT) (WHT)
5	25-7760			Screw
6	35-2669		Not Available	CAP, END (LT)(WHT)
"	35-2668	21001453		Cap- End
7	21001266		Not Available	SHIELD, CONTROL
"	31001193			Pad, Shield
8	53-1816		Not Available	TIMER
"	63-6743	31001484		Resistor Assembly
9	31001119	W10116760		Screw
10	31001234			Switch, Temperature
"	53-1972			Switch, Temperature
11	53-1639			Buzzer Assembly

"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
12	25-7712		Not Available	SCREW
13	31001196		Not Available	KNOB & SKIRT ASSY. (WHT)
14	21001243		Not Available	COVER, CONTROL PANEL (WHT)
15	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	25-3457			Screw, Sems
"	35-2688	21001460		Shield, Rear
16	25-7851			Speedclip, End Cap To Top
17	35-3191			Pushbutton
18	35-3515		Not Available	PAD, SWITCH
19	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	33-6621		Not Available	BRACKET, SWITCH
20	31001241			Switch, Pushbutton
"	31001202		Not Available	SWITCH, PUSHBUTTON
21	16000326			Guide, Quick Ref - Jenn-Air
"	31001221		Not Available	MANUAL, USE & CARE
"	31001222		Not Available	MANUAL, USE & CARE (FCH)

the laundry company®