Maytag A26CD 04 - CABINET



8

Maytag Residential Maytag A26CD Washer Parts Parts Diagram 04 - CABINET
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	200961	12001413		Strainer And Washer Kit
002	205828	202860		Inlet Hose Assembly
003	Y013783			Washer, Inlet Hose
004	Y313561			Screw----NA
005	212276	W10116760		Screw
006	214812	22002361		Bracket, Water Valve
007	201575			Clamp, Hose
008	214337	96160		Screen
009	205614	205613		Water Valve
010	NLA		Not Available	PLATE, ACCESS
011	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
012	212985	22002924		Plate, Access
013	NLA		Not Available	CABINET-WHITE
014	213121	3400111		Screw, 12-14 X 5/8
015	213007			Xfor Cabinet See Cabinet, Back

016	204439			Screw And Fstner Assembly
017	213846			Guard, Belt
018	212998		Not Available	PANEL, FRONT (WHT)
"	212998L		Not Available	FRONT PANEL-ALMOND
"	NLA		Not Available	FRONT PANEL-HARVEST WHEAT
019	212982	22001650		Fastener, Spring
020	214376	22002331		Spacer, Front Panel
021	215058			Pad, Cabinet Bumper
022	214768	211704		Hose, Drain
023	200461	285655		Clamp, Hose
024	211111	16272		Connector, Straight
025	215057	211704		Hose, Drain

the laundry company®
the laundry company®
the laundry company®