Maytag MAF25MC4TL 06 - DOOR LOCK (MAF25MC4Tx)



Maytag Residential Maytag MAF25MC4TL Washer Parts Parts Diagram 06 - DOOR LOCK (MAF25MC4Tx)
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	24001640			Door Lock Complete
"	24001642			Screw, S.s.
002	24001483		Not Available	CATCH, DOOR LOCK
003	24001323			Screw
004	24001484		Not Available	COVER, DOOR LOCK PLATE
005	24001295			Lockwasher, S.s.
006	24001342	74005230		Nut, Lock
007	24001485			Washer, Shoulder
008	24001101			Solenoid, Door Rel
009	24001358			Washer, Flat
010	24001250			Button, Push
011	24001481	Y707702		Locknut
012	24001480			Washer, Teflon
013	24001487		Not Available	COVER, DOOR LOCK ASSY.
014	24001476			Nut, Fiberlock
015	24001229			Switch, Door Lock

016	24001477		Not Available	SPACER, NYLON (No.6)
017	24001479			Screw, S.s.
018	24001643			Screw, S.s.
019	24001301	67006964		Screw, Glide
020	NLA		Not Available	PLATE, DOOR LOCK
021	24001102			Solenoid, Door Lck
022	24001305			Nut, Fiberlock
023	24001255			Switch, Door Handle
"	24001257	24001255		Switch, Door Handle
024	24001425			Nut, Fiberlock, Pltd
025	24001230			Lever, Door Lock
026	24001293			Spring, Torsion
027	24001559			Shim, Door Lock
028	24001488		Not Available	SHIELD, SPLASH (DOOR LOCK)

the laundry company®
the laundry company®
the laundry company®