# Whirlpool WGD97HEXL3 06 - OPTIONAL PARTS (NOT INCLUDED)

Whirlpool Residential Whirlpool WGD97HEXL3 Dryer Parts Parts Diagram 06 - OPTIONAL PARTS (NOT INCLUDED)
Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|---|---|---|---|---|
| NI | 72017 | | | Paint, Touch-Up |
| " | W10363227 | | | Paint, Touch-Up |
| " | W10268217 | | | Paint, Touch-Up |
| " | 350930 | | | Paint, Pressurized Spray B |
| " | 350938 | | | Paint, Pressurized Spray B |
| " | 799344 | | | Paint, Touch-Up ) |
| " | 786032 | | | Refinishing Material |
| " | 8529894 | 346764 | | Kit, Hold Down |
| " | W10323246 | | | Dryer Exhaust Kit |
| " | W10298318RP | | | Paint, Bulk |
| " | 80047 | | | PAINT, BULK (1 QT.) (KIT, DRYER REPAIR) |
| " | W10322470A | | | Paint, Bulk |
| " | W10206708 | W10044609A | | Hose-Kit |
| " | 89503 | | | Hose-Inlet |
| " | 353362 | 285452 | | Hose Screen |
| " | 350027 | 49583 | | Hose-Fill |

| | | | |
|---|---|---|---|
| " | 3357450 | | Washer, Water Inlet Hose |
| " | W10242307 | 16123 | Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately. |
| " | W10269488 | | Connector- Hose, Y |